

## LOCKING BAR

for use with

Counting Stations & Slitting Stations

### INSTALLATION

- Place the center two holes on the Locking Bar over the screw holes on the Counter or Slitter Base Plate.
- Use one flat washer on each screw.
- Screw the screws with washers in the two holes through the Locking Bar and the Counter or Slitter. Make sure to not over tighten the screws. Damaged screws are not covered under terms of warranty.
- Slightly lift the Counter or slitter Unit and slide the Rewinder/Unwinder base plate under the ends of the Locking Bar aligning the screw hole under the grooves on the Locking Bar.
- Screw a screw with washer through the grooves deep enough to hold the screw in place.
- Position the Rewinder and Unwinder to align the label path. Tighten screws on both units making sure not to over tighten screws.
- **IMPORTANT:** Do not lift the units while they are attached to the Locking Bar. The Locking Bar is meant only to keep the units aligned. Bent Locking Bars or broken screws are not covered under Warranty.

### INCLUDED HARDWARE

Screws (4)

Flat Washers (4)

#### **IMPORTANT**

**Do not lift or move the Units together. The Locking Bar must be removed from the Unwinder and Rewinder before moving the Units.**



UserLockingBar.doc