

MAINTENANCE:

Keep the Label Sensor and Stripper Bar clean, following instructions page 1.

Product Limited Warranty

All Labelmate Products are warranted to the original end-user customer to be free from defects in materials and workmanship. If it is determined by Labelmate that a product has failed under the terms of this warranty, the product will be repaired or replaced at no charge to the customer. Labelmate reserves all rights to determination of coverage and liability under this warranty. The warranty period for all new Labelmate products is outlined below:

Warranty Period	Products Covered
5 years	Label Rewinders Label Unwinders
3 years	Label Counters (mechanical parts only) Label Slitters (mechanical parts only) Label Dispensers Printer Mechanisms
1 year	Power Supply Modules Counter modules Encoders Any products not specified above.

The warranty period for all products starts on the date purchased by the original end-user customer. Warranty coverage is not transferable with ownership and will terminate immediately upon rental, resale or any other change in ownership. This warranty does not cover repair to any product which is damaged, has been modified, is missing parts, or has been opened or repaired by any unauthorised person. Use of any unauthorised accessory or attachment will void coverage. Purchase documentation should be retained for coverage verification.

In the event your product requires service, please contact the distributor you bought the product from. The customer assumes responsibility for all cost and risk incurred in transport for service.

Labelmate makes no other warranty of any kind expressed or implied, or to suitability or fitness for a particular purpose. No other person, agent or reseller is authorised to give any warranties on behalf of Labelmate. Any obligation to warranty other than that specifically addressed above is hereby disclaimed.

LABELMATE LLC

69 AVENUE ALPHONSE XIII, 1180 BRUSSELS, BELGIUM

TEL: +322.375.69.60 – FAX: +322.375.38.96

brussels@labelmate.com

www.labelmate.com

© LABELMATE – User_LD – 03/07

LD-100 / LD-200

Powered Label Dispenser



- **High-Low Speed Select**
- **Dispense Transparent and Opaque Labels**

Remove all parts from the shipping container and verify contents.

Package Contents

- *User Manual (this document)*
- *Label Dispenser Unit*
- *Power Supply Module*

VERY IMPORTANT:

- **Keep Label Sensor tips clean. Wipe with a soft cloth occasionally. Be careful not to damage the sensor arms. Do not use any chemical on the Sensor.**
- **Keep Tape Stripper Bar and Web Guide Bars clean. Use isopropyl alcohol or "Goo-Gone"™ to clean adhesive residue from parts. Adhesive build-up can cause malfunction and damage to your unit.**

Retain the Shipping Container and Packaging for Storage and Transport.

- **KEEP MANUAL IN A SAFE PLACE FOR FUTURE REFERENCE**

SPECIFICATIONS:

Max. Label Roll Weight:	4.5Kg (8.8Lb)
Max. Label Roll Size:	220mm (8.7") diameter – 300mm (12") with LD-DE
Power Supply:	Input: 220-240VAC – 50-60Hz. Output: 11VAC – 2.5A





WARNING!
This Product is for indoor use only.
Not for use in wet locations.

SET-UP AND USE:

1. Make sure the Power Switch is in the "OFF" position.
2. Set your LD-100 or LD-200 in place and plug the cord from the Power Supply Module into the Power Input Jack on the rear of the Unit.
3. Connect the Power Supply Module to a suitable AC power source.
4. Place your roll of labels on the Label Roll Holder & slide the Roll Lock Ring onto the Roll Holder to the width of your label web.
5. Thread the label web between the Strip Bar and the Lock Knob Shaft directly above it. *See the threading diagram on the unit.* There should be about 1- to 2-mm between the inside edge of the label web and the Strip Bar frame.
6. Pull the label web under (or over) the round Web Guide and slide the width adjuster to the width of the web.
7. Loop the web UNDER the Wire Bail on the Take-Up Shaft as shown in the illustration.
8. Use "HIGH" or "LOW" Switch setting according to desired speed.
9. The Label Sensor can be adjusted up or down as desired depending on where you want the leading edge of the label to stop. Push in slightly on the Label Sensor while sliding to make adjustment easier.
10. The angle of the Strip Bar must be adjusted if needed according to the length of the label and the angle that it exits the Strip Bar. This is helpful if the label is curling. Loosen the Lock Knob and position the Strip Bar with the small red button. Retighten the Lock Knob.

11. **IMPORTANT:** Pull labels UP when removing them, NOT TO THE SIDE. The optical Label Sensor must be kept clean (see previous page for cleaning instructions).
12. **SENSOR:** The label sensor is factory adjusted. If the label is not correctly detected, you may adjust its sensitivity by turning the potentiometer located on the back of the cover with a screw driver.
13. Optional Flanges for the inside and outside of the label roll are available (order **LD-FLANGES**. Set of two flanges). These Flanges are recommended for narrow or loosely wound labels that may have a tendency to fall off the roll.



OPTIONAL LABEL COUNTER: The optional Label Counter will add one count to the displayed number for each label that is dispensed. This Option is available only factory installed in new Units.

When the LD-100-RS/LD-200-RS is first turned on, it will display a count of "1" or it will display the number from the previous count. You can reset the Label Counter to zero ("0") by pressing the "R" Reset Button.